


Mounting Template













Key 1pc Screw 4pcs Plastic wall anchors 4pcs














Tools:

Protective Eyewear Power Drill with appropriate drill size

Pencil

Screwdriver

Tape Measure



Fasten this mounting sheet to the wall. Preferred height is between 40"-48" from the floor. Use pencil to mark the wall anchor slots that are preferable.

Step 2

Use power drill to drill the 4 marked holes, φ7.5mm and depth 38mm.

Step 3

Use hammer to strike the 4pcs plastic wall anchors inside the holes, ensure the anchors are level with wall.

Step 4

Fasten the dispenser on the wall with 4 screws. Be sure to securely tighten all screws.

Notes: please use the provided screw kits.

